

MODEL NUMBER:

(R) 64020-200-2ADMDFS-A

Document Number: 56A18641E

A Digital Frequency Synthesizer OEM Module with Analog and Digital Modulation input and a 2 Watt RF Output. When specified as R64020-200-2ADMDFS-A, the unit delivered will be manufactured to be compliant with EU Directive 2002/95/EC for Reduction of Hazardous Substance.

<u>PARAMETER</u>	<u>SPECIFICATION</u>		

Bandwidth: 20 – 200 MHz typical

Clock Frequency: 1000 MHz

Step Size: <1 Hz with 30 Bits input

Frequency Settling Time: 250 ns Maximum

Power Out: 2 watts typical

Harmonic Distortion: 2nd: -20 dBc Maximum
3rd: -15 dBc Maximum

Analog Modulation: 0 to +1 volt Analog into 50 Ω , +1 volt = Full RF power output.

Digital Modulation: TTL levels

TTL Active High = Full RF output power
TTL Active Low = Minimum RF output power

No Signal = Full RF output power (pulled high internally)

Rise and Fall Time: 20 ns

Extinction Ratio:

Digital: 30 dB Minimum Analog: 40 dB Minimum

Reference Out: A reference signal from the un-modulated

output of the synthesizer. +0 dBm nominal

Applied Power: + 28 volts DC @ 1 amp Maximum

+ 3.3 volts DC @ 1 amp Maximum

MAXIMUM RATINGS:

Ambient Temperature: 40° C

RF Output: No DC Feedback

Supply Voltage: 30 volts DC

3.5 volts DC

INPUT / OUTPUT CONNECTIONS:

+28v, +3.3V, and Gnd Filtered Feedthru

Mod In SMC Male
Reference Out SMC Male
RF Output SMA Female

"FREQUENCY SELECT" Control TTL 30 bit binary word, Digital Modulation Input, Reset, and a

Latch control input through the 37 pin D sub connector.

See page 2 for pinout.

Outline Drawing 53D3887

1 of 4





64020-200-2ADMDFS-A

"FREQUENCY SELECT" PIN OUT 37-PIN MALE D-SUB CONNECTOR

<u>PIN</u>		<u>PIN</u>	
1	FS_0 LSB	20	FS_1
2	FS_2	21	FS_3
3	FS_4	22	FS_5
4	FS_6	23	FS ₇
5	FS_8	24	FS ₉
6	FS_{10}	25	FS ₁₁
7	FS_{12}	26	FS ₁₃
8	FS_{14}	27	FS ₁₅
9	FS_{16}	28	FS ₁₇
10	FS_{18}	29	FS_{19}
11	FS_{20}	30	FS_{21}
12	FS_{22}	31	FS_{23}
13	FS_{24}	32	FS_{25}
14	FS_{26}	33	FS_{27}
15	FS_{28}	34	FS ₂₉ MSB
16	Latch	35	Digital Modulation Input (Active High)
17	Master Reset (Active High)	36	N/C
18	N/C	37	N/C
19	Ground		

Control Word
$$K_{10} = \frac{F_{OUT\,(Hz)}(2^{31})}{F_{OSC\,(Hz)}}$$
 in Decimal notation

CONTROL WORD CALCULATIONS

The output frequency and step size is a function of the clock rate and the "FREQUENCY SELECT" data. The output frequency can be calculated from the formula:

$$f_{out} = \frac{(f_c)(k_{10})}{2^n}$$

Where: $f_c = \text{clock frequency in Hz}$

 k_{10} = input word in decimal notation

n = 31 *See note below.

The minimum output frequency and step size are given by:

$$f_{\text{min}} = \frac{f_c}{2^n}$$

An example of setting the frequency:

Clock frequency = $1000 \times 10^6 \text{ Hz}$

Desired output frequency = $30.00 \times 10^6 \text{ Hz}$

$$K_{10} = \frac{f_{OUT (Hz)}(2^{31})}{f_{OSC (Hz)}}$$

$$K_{10} = \frac{30 \times 10^6 (2^{31})}{(1000 \times 10^6)}$$

 $K_{10} = 64424509.44$ Decimal

Convert K₁₀ to HEX

V- MSB ∨ - LSB

 $K_{HEX} = 3D70A3D$

03D70A3D

-Setting for front panel "HEX" switches NOTE: The switches on the front panel of the driver are LSB to MSB - right to left.

∨ LSB - pin1

Convert K_{HEX} to Binary

 $K_{\rm B}\!=\!\!\underline{0000}11110101110000101000111101$

-Setting for binary word input to back panel "FREQUENCY SELECT" 37 pin

These 4 bits are added to complete the 30 bit word


D-sub connector

*Note: This system only uses 30 bits to set the frequency output from the driver. The accumulator inside the chip is 31 bit, so use 2³¹ in your calculations for precision.


The LATCH function (pin 16) is a TTL compatible input which is used to load new frequency information into the driver. Frequency data is loaded into the driver when the signal on the LATCH pin goes from HIGH to LOW (falling edge).

Master RESET is a TTL active HIGH and resets the accumulator to zero, ie, no frequency output, when a TTL HIGH is applied to pin 17. This is pulled LOW via. a 1 K Ω resistor.

To generate a single frequency, apply the binary frequency word to the FS input, A falling edge on the LATCH input will then load the data and change the frequency.



To generate a ferquency chirp, set the starting frequency as above and then apply the delta word to the FS input. A falling edge on DLATCH will then load the delta frequency word and initiate the chrip. The chirp will stop and output will return to to starting value or a rising edge.



For More Information, Contact: sales@goochandhousego.com www.goochandhousego.com

As part of our policy of continuous product improvement we reserve the right to change specifications at any time.

4 of 4



